

1) Connect the cables

(a) **Original Xbox 360 console (Figure 1)**

- Plug one end of the cable into the USB port on the back of the console and the other end into an electrical outlet.
- If you have a wireless networking adapter, plug it into the USB port on the front of the console by using the supplied USB extension cable.
- Move all other USB accessories to USB ports on the front of the console.



Figure 1



Figure 2

(b) **Xbox 360 S console (Figure 2)**

- If the Kinect sensor is attached to a cable with a power plug, disconnect the power plug portion of the cable. A power cable is not needed with the Xbox 360 S console.
- Plug the sensor cable into the AUX port on the back of the console.

2) Methods to turn on your Xbox 360 console and your Xbox 360 Wireless Controller

- To turn on your Xbox 360 console and your Xbox 360 Wireless Controller, press the **Xbox Guide** button on the controller.
- To turn on your Xbox 360 console only, press the power button on the console.
- To turn on your Xbox 360 Wireless Controller only, press the **START** button on the controller.

3) **Setting Up Xbox Kinect**

(a) Sensor Placement (Kinect sensor needs to see your entire body)

- Place the sensor near the edge on a flat, stable surface.
- Position the sensor between 2 feet (0.6m) and 6 feet (1.8m) from the floor. Ideally, the sensor should be within 6 inches (15 cm) above or below your TV.
- Avoid positioning the sensor in direct sunlight or within 1 foot (.3m) of audio speakers.
- Do not manually tilt the sensor, it adjusts automatically.
- Be careful not to drop the sensor.

(b) Room To Play (Kinect needs to be able to see your entire body)

- Clear the area between the sensor and the players.
- One player: Stand back 6 feet (1.8 m).
- Two players: Stand back 8 feet (2.4 m).
- Make sure that the play space is at least 6 feet (1.8 m) wide, and not wider or longer than 12 feet (3.6 m).
- Make sure the room has bright, even lighting.

4) **Navigating**

Using Kinect is easy. Wave your hand so that the sensor can see you. Moving your hand moves the pointer on the screen. To select an item, hold your hand over it until the ring completes.

5) **Kinect Guide Gesture**

Hold your left hand out and down to bring up the Kinect Guide. The Kinect Guide allows you to pause a game, check out your profile and friends, tune your sensor or access the Kinect Hub where you can explore other Kinect experiences.

6) **Methods to turn off your Xbox 360 console and your Xbox 360 Wireless Controller**

- To turn off your Xbox 360 console and your Xbox 360 Wireless Controller, press and hold the **Xbox Guide** button on the controller for three seconds. Next, select whether you want to turn off just the controller or both the controller and the console. If you select the console, the console and all connected controllers are turned off.
- To turn off only the console, press the power button on the console.